



Instructions for Vangear Campervan Units

Thank you for purchasing a unit from Vangear. For more information please visit www.vangear.co.uk

Please check for damages and report them within 48 hours of receiving the unit. Please keep the original packaging in case you need to return the unit.

We appreciate any feedback about our units. We would also appreciate any photos or videos of your unit in your van that we could use on Facebook and social media.

e-mail us at: info@vangear.co.uk

<https://www.facebook.com/vangearcampervanunits/>

<https://www.instagram.com/vangear/>

We have fitting videos on our website and YouTube channel.

- Please check for delivery damage and keep any packaging.
- We have designed our units to be simple to fit, however, if you do not feel confident with any part of the installation please ask for advice.
- Use the power cable to connect to the 12v power. Pass the cable through hole in the base of the unit (the cable can easily be stretched out).
- Always empty the waste bottle at the same time as filling the water bottle to avoid overfilling the waste bottle.
- When using the tap for the first time, turn the tap on/off a few times to clear any air.
- We have supplied a Campingaz regulator (not Nano) for the Campingaz bottle R904
- Instructions for the gas hob are included (Dometic or CAN). The guarantee for the hob is handled via Dometic service centres. Please refer to the Dometic website:
<https://www.dometic.com/en-gb/uk/support>
- The guarantee for the Vitrifrigo c39i is handled by Penguin Frigo:
<https://penguinfrigo.co.uk/service-and-support/campervan-and-motorhome/12-24-dc-refrigeration/>
- We kindly request that you thoroughly test all of the functions of your pod before going on holiday

Safety Information

- Only use the hob in well ventilated areas.
- Never close the lid when the burner is alight.
- Never change the gas bottle near naked flame.
- Always shut off the gas bottle at the regulator during transit.
- Use a CO2 alarm, check the battery regularly.
- Never leave your lit hob unattended.
- If the tambour door is stiff use silicone spray to lubricate the door tracks.
- Make sure the hob pot holders are pushed fully home to avoid rattles on the glass lid.

Fitting Instructions:

- Take care when drilling through the van floor.
- There are mounting slots in the base of the units and the units can be fixed to the floor using the supplied bolts or one of our anchor cleats.

1. Position and dry fit the unit in place to check the positions of all units relative to van
2. Hint - it's a good idea to mark the positions with masking tape
3. Mark the fixing holes through the slots in the base of the unit
4. Drill holes
5. Pass power cable through the slots in the base
6. Re position unit and fix with hex bolts
7. Or use the anchor cleat option to fit to rail system i.e. VW Caravelle, California Beach etc
8. Anchor cleats for the VW rail system slide into the rail through plastic caps at the end of the rails.

Nano unit

The tap head is loose in the fittings bag (to stop damage in delivery) and needs to be pushed on hard onto the tap

Kombi/XS/Maxi

- These units use the Campingaz R904 (large) or R901 (small).
- For the Maxi only, the large table fits inside the unit with the leg on the left and clips on the right.
- For instructions on the hobs please refer to the included instruction manuals.
- Due to the numerous positionings of the units there may be the need for drilling an additional in the plywood base of the unit.

Maxi Fridge

- The 12v leads can be fed through the vents behind the fridge
- The 10 litre waste bottle will be placed at the rear with the 9 litre (thinner) bottle placed at the front.

Modular system

- Always dry fit the units first to work out their positions relative to the van
- After reference to fitting instructions above:
- If necessary, the overhang on the wheel arch unit has can be cut with a handsaw or a jigsaw with a downward cutting jigsaw blade
- Fix the wheel arch unit to the floor via the 3 mounting slots.
- The top storage unit is fixed with the provided bolts to the wheel arch unit. It may be necessary to fix the top storage unit to the side of the van with a bracket.

Find us at:

Email: info@vangear.co.uk

Tel: 01444 247129 Mobile: 07810 592353

www.facebook.com/Vangearcampervanunits

www.youtube.com/c/vangearuk

www.instagram.com/vangear

Design registered and copyrighted at Intellectual Property Office